Block PCNTRL

The PCNTRL block...



DUMMY

Name	PCNTRL
Function	pp0017
Inputs	3
Outputs	1
Parameters	5
Strings	0
Group	L

Inputs

1 Storage content
2 Former mass flow mp
3 Storage outlet temperature Tout

Outputs

1 Mass flow for power plant

Parameters

1 Intial value for INITOL (OLD!!!!!)
2 mp value
3 Cut in setpoint
4 Cut off setpoint
5 Switch off temperature setpoint

Strings

None

Remarks