Block MBE

The MBE block calculates the mean bias error between the input signals over a complete simulation run.



Name	MBE
Function	fb0075
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

1	Simulated time series x_{s}
2	Measured time series x_{m}

Outputs

1	Mean bias error

Parameters

None

Strings

None