

Block AVEW

The AVEW block calculates the weighted average of its inputs.



DUMMY

Name	AVEW
Function	fb0078
Inputs	2
Outputs	1
Parameters	2
Strings	0
Group	S

Inputs

- 1 Any signal T_1
- 2 Any signal T_2

Outputs

- 1 Weighted average $\bar{T}_w$

Parameters

- 1 Weight one w_1
- 2 Weight two w_2

Strings

None