

Block CNTRL

The CNTRL block...



DUMMY

Name	CNTRL
Function	pp0010
Inputs	3
Outputs	1
Parameters	6
Strings	0
Group	S

Inputs

- 1 Collector mass flow
- 2 Collector outlet temperature
- 3 Collector inlet temperature

Outputs

- 1 New mass flow

Parameters

- 1 Setpoint temperature
- 2 Ausgangswert m1
- 3 Temperature tolerance DT
- 4 Minimum flow mmin
- 5 Maximum flow mmax
- 6 Maximum number of iterations maxit

Strings

None
