

Block HR

The HR block calculates the radiative heat transfer coefficient for two surfaces with a view factor $F_{1\rightarrow2}$.



Name	HR
Function	bs0021
Inputs	3
Outputs	1
Parameters	4
Strings	0
Group	S

Inputs

- 1 T1
- 2 T2
- 3 F12

Outputs

- 1 hr

Parameters

- 1 A1
- 2 A2
- 3 Emissivity of surface one
- 4 Emissivity of surface two

Strings

None