


Block IFNEG

The IFNEG block returns its input signal only if it is negative.

If...<0
Then
...



Name	IFNEG
Function	fb0046
Inputs	1
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

- | | |
|---|----------------|
| 1 | Any signal x |
|---|----------------|

Outputs

- | | |
|---|--|
| 1 | Signal x in case of $x < 0$, otherwise the successors of this block are not executed. |
|---|--|

Parameters

None

Strings

None

ifneg.vseit



In a **DO** block numbers are counted from -1 to $+1$. The **IFNEG** block checks whether the output of the **DO** block is negative. If yes, the **SCREEN** block displays the value, otherwise execution of the **SCREEN** block is skipped.

-1.0