

Block MAE

The MAE block calculates the mean absolute error between the input signals over a complete simulation run.



Name	MAE
Function	fb0075
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs	1	Simulated time series x_s
	2	Measured time series x_m
Outputs	1	Mean absolute error
Parameters		None
Strings		None