


Block NOP

The NOP block performs no operation except setting the output value equal to the input.



Name	NOP
Function	fb0005
Inputs	1 ... [10]
Outputs	1 ... [10]
Parameters	0
Strings	0
Group	S

Inputs

i Any value x_i

Outputs

i Value of x_i

Parameters

None

Strings

None

nop.vseit



The [CONST](#) block provides a constant with value 1. The [NOP](#) block passes its input through and the [SCREEN](#) block displays the result.

1.0