

Block SCHEDU

The SCHEDU block determines the current value, e.g. for internal gains or aim-temperature, according to a time-schedule for days during the week and on weekend.



SCHEDU

Name	SCHEDU
Function	bs0012
Inputs	2
Outputs	2
Parameters	54
Strings	0
Group	S

Inputs

- 1 Integer nr. from calendar-block [-]
- 2 Minute of the day [min]

Outputs

- 1 Current value [e.g. W, degC]

Parameters

- 1+3*n From Time [h]
2+3*n Until Time [h]
3+3*n Value

Strings

None
