

Block SPEAR

The SPEAR block calculates Spearman's rank correlation coefficient of its inputs over a complete simulation run.



DUMMY

Name	SPEAR
Function	fb0076
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

- 1 Any signal x_i
- 1 Any signal y_i

Outputs

- 1 Spearman's rank coefficient r_s over all (x_i, y_i)

Parameters

None

Strings

None
