

Block FACADE

The FACADE block calculates the outlet temperature of...



Name	FACADE
Function	bs0020
Inputs	7
Outputs	1
Parameters	1
Strings	0
Group	S

Inputs

- 1 Tin
- 2 T1
- 3 T2
- 4 hc1
- 5 hc2
- 6 v
- 7 x

Outputs

- 1 T(x)

Parameters

- 1 Gap width *s*

Strings

None