


Block IFNEG

The IFNEG block returns its input signal only if it is negative.

If...<0
Then
...



Name	IFNEG
Function	fb0046
Inputs	1
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

- 1
- Any signal x

Outputs

- 1
- Signal x in case of $x < 0$, otherwise the successors of this block are not executed.

Parameters

None

Strings

None

ifneg.vseit



In a DO block numbers are counted from -1 to $+1$. The IFNEG block checks whether the output of the DO block is negative. If yes, the SCREEN block displays the value, otherwise execution of the SCREEN block is skipped.

-1.0