Block AVEW

The AVEW block calculates the weighted average of its inputs.



DUMMY

Name	AVEW
Function	fb0078
Inputs	2
Outputs	1
Parameters	2
Strings	0
Group	S

Inputs

1	Any signal T_1
2	Any signal T_2

Outputs

1	Weighted average $barT_{\mathrm{w}}$

Parameters

1	Weight one w_1
2	Weight two w_2

Strings

None