Block HR

The HR block calculates the radiative heat transfer coefficient for two surfaces with a view factor $F_{1\to2}$.



Name	HR
Function	bs0021
Inputs	3
Outputs	1
Parameters	4
Strings	0
Group	S

Inputs

1	T1
2	T2
3	F12

Outputs

1	hr

Parameters

1	A1
2	A2
3	Emissivity of surface one
4	Emissivity of surface two

Strings

None