
## Block IFNEG

The IFNEG block returns its input signal only if it is negative.




| | |
|---|---|
| **Name** | IFNEG |
| **Function** | fb0046 |
| **Inputs** | 1 |
| **Outputs** | 1 |
| **Parameters** | 0 |
| **Strings** | 0 |
| **Group** | I |

Inputs

1 Any signal $x$

Outputs

1 Signal $x$ in case of $x < 0$, otherwise the successors of this block are not executed.

Parameters

None

Strings

None

ifneg.vseit




In a DO block numbers are counted from $-1$ to $+1$. The IFNEG block checks whether the output of the DO block is negative. If yes, the SCREEN block displays the value, otherwise execution of the SCREEN block is skipped.

```
-1.0
```