Block MAE

The MAE block calculates the mean absolute error between the input signals over a complete simulation run.



Name	MAE
Function	fb0075
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

1 Simulated time series x_s
2 Measured time series x_m

Outputs

1 Mean absolue error

Parameters

None

Strings

None