Block RMAE

The RMAE block calculates the relative mean absolute error between the input signals over a complete simulation run.



Name	RMAE
Function	fb0075
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

1 Simulated time series x_{s}
2 Measured time series x_{m}

Outputs

1 Relative mean absolute error

Parameters

None

Strings

None