Block RRMSE

The RMSE block calculates the relative root mean square error between the input signals over a complete simulation run.



Name	RRMSE
Function	fb0075
Inputs	2
Outputs	1
Parameters	0
Strings	0
Group	I

Inputs

1 Simulated time series x_{s}
2 Measured time series x_{m}

Outputs

1 Relative root mean square error

Parameters

None

Strings

None