Block SCHEDU

The SCHEDU block determines the current value, e.g. for internal gains or aim-temperature, according to a time-schedule for days during the week and on weekend.



Name	SCHEDU
Function	bs0012
Inputs	2
Outputs	2
Parameters	54
Strings	0
Group	S

Inputs

1	Integer nr. from calendar-block [-]
2	Minute of the day [min]

Outputs

1	Current value [e.g. W, degC]

Parameters

1+3*n	From Time [h]
2+3*n	Until Time [h]
3+3*n	Value

Strings

None