
Block NOP

The NOP block performs no operation except setting the output value equal to the input.





Name	NOP
Function	fb0005
Inputs	1 . . . [10]
Outputs	1 . . . [10]
Parameters	0
Strings	0
Group	S

Inputs

i	Any value x_i

Outputs

i	Value of x_i

Parameters

None

Strings

None

nop.vseit



The CONST block provides a constant with value 1. The NOP blocks passes its input through and the SCREEN block displays the result.

```
1.0
```