


Block DPPARA

The DPPARA block calculates the pressure drop of channels connected in parallel.



Name	DPPARA
Function	st0024
Inputs	2 ... [10]
Outputs	1
Parameters	0
Strings	0
Group	S

Inputs

- 1 Pressure drop of channel 1 Δp_1 / Pa
- 2 Pressure drop of channel 2 Δp_2 / Pa
- N Pressure drop of channel N Δp_N / Pa

Outputs

- 1 Overall pressure drop Δp / Pa

Parameters

None


Strings

None

Description The overall pressure drop Δp is calculated from the parallel connected input pressure drops $\Delta p_1, \Delta p_2, \dots \Delta p_N$ by

$$\frac{1}{\Delta p} = \sum_{i=1}^N \frac{1}{\Delta p_i}$$

dppara.vseit



The most trivial application of the [DPPARA](#) block is that two channels with a pressure drop of 1 Pa each are connected in parallel so that the resulting pressure drop becomes 0.5 Pa as displayed by the [SCREEN](#) block.

0.50