


Block WINDOW

The WINDOW block calculates the total energy flux through a window, with a detailed model of the solar heat gain coefficient.



Name	WINDOW
Function	bs0008
Inputs	5
Outputs	5
Parameters	8
Strings	0
Group	S

Inputs

- 1 Global radiation in the window plane $G_t / \text{W m}^{-2}$
- 2 Beam radiation in the window plane $G_{bt} / \text{W m}^{-2}$
- 3 Incidence angle θ of the beam radiation over the window in degrees
- 4 Ambient air temperature $T_a / ^\circ\text{C}$
- 5 Inside air temperature $T_{in} / ^\circ\text{C}$
- 6 Radiative heat flux inside

Outputs

- 1 Total heat flux through the window, from outside to inside $\dot{Q}_t / \text{W}$
- 2 Beam radiation transmitted through the window $\dot{Q}_b / \text{W}$
- 3 Diffuse radiation transmitted through the window $\dot{Q}_d / \text{W}$
- 4 Inside surface temperature $T_{si} / ^\circ\text{C}$
- 5 Outside surface temperature $T_{so} / ^\circ\text{C}$

Parameters

- 1 Global U -value including window frame $/ \text{W m}^{-2} \text{K}^{-1}$
- 2 Number of window panes N_p
- 3 Total window Area A / m^2

- 4 Frame fraction of the total window area
- 5 Optical absorption coefficient α of inner glass pane
- 6 Normal solar heat gain coefficient, without shading SHGC_n
- 7 Normal solar heat gain coefficient, with shading SHGC_{sh}
- 8 Global radiation threshold above which one the shading devices are set on $G_{th} / \text{W m}^{-2}$

Strings

None

Remarks The WINDOW block calculates the total heat flux through the window (solar gains and transmission losses), the short wave radiation transmitted through the window, and both surface temperatures.